

## **Antimicrobial Fabric Protection**

## **SHOWER and CUBICLE CURTAINS**

#### Flame Resistant

Sure-Chek fabrics resist combustion and will selfextinguish when the source of flame is removed.

#### Stain Resistant

Most oils, greases, and contaminants may be wiped off with soap, water or mild cleansers. Curtains are easily cleaned in place and maintain a fresh look.

#### Antistatic

Sure-Chek fabrics are specially formulated with an enduring antistatic property, "Anstat"." It prevents the build-up or retention of electrostatic charges that could interfere with the functioning of sensitive life support equipment.

#### **Odor Resistant**

Sure-Chek fabrics have been treated to resist bacterial odors. Objectionable organic odors are decreased as a result of the active protection against odor-forming bacterial growth on fabric surfaces.

#### Durable

Sure-Chek fabrics are incredibly strong, withstanding severe wear and abuse. Extra strength and tear resistance mean extended curtain life.

#### Antimicrobial to protect the fabric

A controlled release system continually sends the antimicrobial agent to the fabric surface. This built-in protection lasts the life of the fabric. It is not a superficial treatment.

#### Decorative

Sure-Chek fabrics offer an attractive selection of contemporary colors with a crisp linen finish.

#### **Economical**

Lower replacement costs, less inventory, minimal care and maintenance all add up to true economy. Costconscious buyers specify high performance Sure-Chek fabrics for their cubicle and shower curtains.

#### **Available**

in 9 colors shown, 72" fabric width, 100 yds. per roll

Mauve

Translucent

Dune

Fawn

White


Light Blue

Mint

Seafoam

### SHOWER and CUBICLE CURTAINS

## Recommended Care



Hard to Clean Spots: Standard household/vinyl cleansers and/or a soft bristle brush can be used for removing troublesome spots or stains. Heavy "dried on" soil may first require soaking to loosen. DO NOT USE HARSH CLEANSERS OR SOLVENTS.

Herculite Products does not recommend the laundering of Sure-Chek healthcare fabrics since laundering may substantially decrease the useful life of these fabrics. However, if laundering is required, follow the procedures of the International Fabricare Institute:

- Wash and rinse according to the "Synthetic Washing Procedure for Coated Fabrics" with temperatures not exceeding 100° F. (See below).
- 2. Extract water with centrifugal extractor.
- 3. Tumble dry in a steam dryer (not gas) at 120° F maximum. For tailored, precise fitted items, tumble dry without heat or air dry. DO NOT IRON.

# Synthetic Washing Procedure for Coated Fabrics

(International Fabricare Institute Commercial Washroom Procedures)

## AICSA

Tel.: (506) 2281-2257 / Fax: (506) 2281-2256 msa@aicsa.com.mx www.aicsa.com.mx Apartado Postal: 13381 - 1000 San José, COSTA RICA

Operation	Water Level	Time	Maximum Temperature	Supplies
1st Suds	High	5 Min.	100°F	Neutral Soap & Alkali
2nd Suds	High	10 Min.	100°F	Neutral Soap & Alkali
1st Rinse	High	3 Min.	100°F	Water
2nd Rinse	Low	3 Min	90°F	Sour to pH 5.0

Use a slow speed machine. Stop the wash wheel for draining and refilling between each cycle.



3555 Scarlet Oak Blvd. • St. Louis, MO 63122 800.377.6625 p • 636.225.9090 f • arnelson.com